

Installation instruction for the 25 mm die set for the 1900A

Thank you for purchasing our Australian made 25 mm die set for the 1900A.

The adaptor is gold in colour. To install the adaptor, attach it to the underside of the shaft with the 5/32 allen key supplied.

The top die is silver in colour. To install the top die, slide it onto the bottom of the adaptor and line up the centre punch mark with the groove on the frame body. Tighten the screw. The screw should be at 5 o'clock to the grooved mark on the body of the machine.

NB When making your badges you must insert the pin **after** you have made the badge, this is your final step.